

# ICON Extreme Ambient Shipper



Select shipper and remove inner lid.



Place 1 polar pack in bottom of box.



Place 95kPa bio bag on polar pack.



Place 2<sup>nd</sup> and 3<sup>rd</sup> polar packs on 95kPa bag.



Place lid on foam box.



Fold in side flaps of shipper.



Secure shipper lid.



Place adhesive strip on shipper.



Place completed airbill on shipper.