



Biological Substance, Ambient

Packaging Instructions

1. Ship samples in an ICON lab kit box with a copy of the requisition for that visit inside. Place the sealed ICON lab kit box into the Shipper (Laboratory) Pak provided by QuickStat. Up to two ICON lab kit boxes will fit inside the Shipper (Laboratory) Pak.
2. Remove the adhesive strip and seal the bag.
3. Affix the appropriate completed air waybill to the Shipper (Laboratory) Pak provided by Quick STAT.